SPECIFICATIONS

SPEC. No. CC - 1161 DATE APR. 2018

SPECIFICATIONS HYDRAULIC CRANE

MODEL: UNIC URW376C4EMR

Specifications are subject to change without notice.

EXPORT TECHNICAL DEPT TOKYO JAPAN

UNIC CRANE PERFORMANCE MODEL: URW376C4EMR

CRANE CAPACITY:

LIFTING CAPACITY: Max 2.93t at 2.5m

HOOK HEIGHT

ABOVE GROUND LEVEL : Max 14.9m

BELOW GROUND LEVEL : Max 18.7m with 4-part line

WORKING RADIUS : Min 0.62m, Max 14.45m

BOOM: 6-section box beam type telescoping boom

Boom Length

Retracted boom: 3.63m
Extended boom: 14.61m

Boom Extending Speed: 10.98m/23 s Boom Raising Speed: 0° to 80°/10 s

WINCH: Hydraulic motor driven, spur gear reduction,

with automatic mechanical brake and wire rope retaining roller.

Hoisting Speed

Single line speed: 68.0m/min at 4th layer

Hook speed: 17.0m/min at 4th layer with 4-part line

Hook Block; 2.9t capacity, 2 sheaves with safety latch

Wire Rope

Construction (JIS): IWRC 6 ×WS (26) GRADE B

Diameter X Length: 8mm ×85m

Breaking strength: 42.4kN (4320kgf)

SLEWING: Hydraulic motor driven, worm gear reduction, spur

gear reduction, and worm self-locking brake

(supported by ball bearings)

Slewing Range: 360° continuous rotation on a ball bearing race

Slewing Speed: 2.5 rpm

OUTRIGGERS:

Horizontal: A double acting hydraulic cylinder, direct pushing type

(directly connected with hydraulic automatic lock device)

Vertical: A double acting hydraulic cylinder, direct pushing type

(directly connected with hydraulic automatic lock device)

HYDRAULIC SYSTEM:

Hydraulic Pump

Type: Variable delivery piston pump

Rated pressure: 21.6MPa (220kgf/cm²)

Rated delivery: $60 \, \ell/\text{min}$. Rated revolution: $2500 \, \text{rpm}$ Hydraulic oil tank: $75 \, \ell$ capacity

Hydraulic Valves

Control valve: Multiple control valve, spring centered,

spool-type, with pressure relief valve

Pressure relief

valve setting: For crawling:21.6MPa (220kgf/cm²)

For crane: 20.6MPa (210kgf/cm²)

Counterbalance valve:

Boom raising and boom telescoping cylinders

Pilot-operated

check valve: Outrigger cylinders (Horizontal)

Double pilot-operated

check valve: Outrigger cylinders (Vertical)

Hydraulic Actuators

Hydraulic motors: Hoisting: Axial plunger type

Slewing: Axial plunger type

Hydraulic cylinders: Double acting type

1 × Boom raising cylinder
1 × Boom telescoping cylinder
4 × Outrigger cylinder (Horizontal)
4 × Outrigger cylinder (Vertical)

CRAWLING GEAR:

Crawling: Endless rubber crawler

Crawler: 300 × 52.5× 88

Tread length: 1750mm

Ground contact pressure: 37.3kPa (0.38kgf/cm²)

Crawling speed: 0~3km/h, forward/reverse

Hill climbing ability: 23°

Engine: Rated output: 15.2kW (20.7ps)/2500rpm

Model: 3TNV80F-SNFK

(YANMAR Co., Ltd)

Displacement: 1266 cm³

Fuel Type: Diesel Oil

Steering: Hydraulic drive independent of left/right

Parking brake: Disc brake with hydraulic motor built-in

Starter: Starter motor Fuel tank: 40 ℓ capacity

Note: The figures in relation to the speed are on the basis of no-load running at rated oil flow condition.

MAJOR SPECIFICATION OF ELECTRIC POWER UINT

Power unit

Hydraulic pump

Type

Variable delivery piston pump

Rated pressure

21.6MPa (220kgf/cm²)

Frequency (Hz)	50			60				
Voltage (V)	380	400	415	400	440	460		
Rated revolution (rpm)	1460	1460	1465	1755	1760	1765		
Rated delivery (litters/min)	Approx.27			Approx.32				

Motor

Rated output

7.5kW (3-phase 4 poles)

Rated Frequency (Hz)		50	*	60			
Rated Voltage (V)	380	400	415	400	440	460	

Allowable range: 50/60Hz±5%

AC380,400,415/400-460V±10%

Control box

Rated Frequency (Hz)	l	50			60	
Rated Voltage (V)	380	400	415	400	440	460

Allowable range: 50/60Hz±5%

AC380,400,415/400-460V±10%

Starting-up

Direct start-up

Crane power supply

DC12V (120W) output

With AC/DC converter built-in

Power cable

Power connector

Cord connector body made by American

Electric Work (accessory)

Type: 4364R

Part number: 750501228

Power cable

Vinvl cab-tire cable of 4-core cable

(To be prepared by customer)

Type: VCT4X5.5mm² (Outside diameter of cable

is up to ϕ 16.)

Part number: 750604057

(Cable length is to be specified by customer. It is

up to 50m.)

Crimp terminal

Type: R5.5-5(To be prepared by customer) Part number: 750509058(Nitifu TGV5.5-5)

Specified speed when using electric power unit

<50Hz>

<60Hz>

Hoisting Speed Single line speed

34m/min

40 m/min (at 4th layer)

Hook speed

8.5m/min

10 m/min (at 4th layer with 4-part line)

Boom extending Speed

10.98m/40s

10.98m/33.5s

Boom Raising Speed

0° to 80° / 18s

0° to 80° / 15s

Slewing Speed

2.1rpm

2.5rpm

Crawling Speed (forward/reverse)

0-1.3km/h

0-1.5km/h

Caution Do not use engine and electric power unit together.

> Be sure to confirm before stating the electric power unit that the engine has been stopped. Please specify when ordering specification of 380V/50Hz or 415V/50Hz, if you want to request

them.

SAFETY DEVICES:

- 1. Pressure relief valve for hydraulic circuit
- 2. Counterbalance valves for boom raising and boom telescoping cylinders
- 3. Pilot-operated check valves for outrigger cylinders (Horizontal)
- Double pilot-operated check valves for outrigger cylinders (Vertical)
- 5. Boom angle indicator with load indicator
- 6. Hook safety latch
- 7. Automatic mechanical brake for winch
- 8. Automatic stop for overwinding
- 9. Overwinding alarm
- 10. Automatic stop for leaving minimum wire rope
- 11. Emergency stop button
- 12. Inter-lock device of crane and crawling levers
- 13. Inter-lock device of crane and outriggers (Option: Outrigger ground contact detector)
- 14. Level
- 15. Three colored lamp
- 16. Headlight

VOICE MESSAGE:

[Remote control active]

[Stop winch up]

[Secure lifting hook]

[Low transmitter battery]

[Service remote control]

[Reset main switch]

[Change control mode]

[Crane mode]

[Outrigger mode Outriggers moving]

[Check error code]

[Control system error]

DIMENSIONS OF CRANE:

4375mm (L) × 1300mm (W) × 1805mm (H)

MASS OF CRANE:

4020kg

REMOTE CONTROLLER: (Radio controller model or Cable remote controller model)

Model:

RC-500HA-AUS

System:

Manual/remote control combined system

Control:

1. Selective control

Raise / Lower Boom

(Crane mode/Outrigger mode)

Outrigger 4 Ret / Ext

Hook Hoist / Lower

> (Shock-less ON / OFF) Outrigger 3 Ret / Ext

Boom Extend / Retract

(Outrigger Horizontal Nertical)

Outrigger 2 Ret / Ext

C.W / C.C.W Slewing

> (Eng. start / stop) Outrigger① Ret / Ext

2. Store hook

Hook storage

3. Start/Warning horn

Start radio remote control and recovered emergency stop/ Horn

4. Speed control lever

Hydraulic control and engine

speed control

5. Mode select

Crane mode/Outrigger mode

(Shock-less ON/OFF) Outrigger horizontal/vertical

(Engine Start / Stop)

6. Speed mode select

High speed mode (normal mode)/

Medium speed mode/Low speed mode

7. Key switch

8. Emergency-stop switch

Transmitter power on-off Stop function of crane

Controller Power supply:

Transmitter

Crawler battery (DC12V)

Four R03 dry cells (DC6V)

Power consumption:

Approx. 50 W

(Single selective operation at maximum operating speed)

Transmitter:

Battery life more than 20 hours (of transmitter operation)

Transmitter weight:

700g (with batteries)

Ambient temperature:

-20 °C ~ +60 °C

Storage temperature:

-30 °C ~ +75 °C

RADIO: (Radio remote controller model)

Radio frequency:

433 ~ 434 MHz Band

Transmitted output power: 10mW

Operating range:

Approx. 100m

Unit address:


Special address combining a frequency and ID code is

assigned to each unit.

Caution

In accordance with our policy of constant product improvement, all specifications are subject to change without notice or obligations.

WORKING RANGE:



Note: The above figures are based on no-load condition and do not include the deflection of the boom.

NET RATED LOADS:

Boom-sections extended: ①, ①+②

Worl	Working radius (m)		2.5	3.0	3.5	4.0	4.5	5.0	5.69
	Outriggers extended to maximum		2.9	2.35	1.95	1.67	1.45	1.3	1.07
Net Rated load (t)	Outriggers extended to halfway	2.9	2.9	2.32	1.92	1.57	1.25	0.99	0.77
	Outriggers extended to minimum	2.9	2.9	2.17	1.5	1.12	0.9	0.72	0.47

Boom-sections extended: ①+②+③

Worl	Working radius (m)			3.5	4.0	4.5	5.0	5.5	6.0	7.0	7.88
	Outriggers extended to maximum		2.09	1.65	1.4	1.22	1.07	0.95	0.84	0.69	0.59
Net Rated load (t)	Outriggers extended to halfway	2.24	2.06	1.65	1.39	1.17	1.0	0.82	0.64	0.45	0.37
	Outriggers extended to minimum	2.24	2.06	1.57	1.22	1.02	0.83	0.65	0.51	0.3	0.19

Boom-sections extended: 1+2+3+4

Worl	4.0	4.5	5.0	6.0	7.0	8.0	9.0	10.07		
	Outriggers extended to maximum	1.04	0.93	0.84	0.73	0.62	0.52	0.47	0.38	
Net Rated load (t)	Outriggers extended to halfway	1.03	0.92	0.83	0.67	0.5	0.38	0.28	0.2	
	Outriggers extended to minimum	1.03	0.82	0.64	0.47	0.31	0.22	0.13	0.09	

Boom-sections extended: 1+2+3+4+5

Worl	4.5	5.0	6.0	7.0	8.0	9.0	10.0	11.0	12.26	
	Outriggers extended to maximum	0.75	0.62	0.48	0.39	0.34	0.3	0.27	0.24	0.23
Net Rated load (t)	Outriggers extended to halfway	0.75	0.62	0.48	0.39	0.32	0.27	0.22	0.17	0.13
	Outriggers extended to minimum	0.75	0.62	0.4	0.25	0.18	0.13	0.09	0.06	0.01

Boom-sections extended: 1+2+3+4+5+6

Worl	Working radius (m)		5.5	6.0	7.0	8.0	9.0	10.0	11.0	12.0	13.0	14.45
Outriggers extended to maximum		0.3	0.27	0.25	0.22	0.2	0.18	0.16	0.14	0.13	0.11	0.1
Net Rated load (t)	Outriggers extended to halfway	0.3	0.27	0.25	0.22	0.2	0.18	0.16	0.12	0.09	0.06	0.04
	Outriggers extended to minimum	0.3	0.27	0.25	0.22	0.17	0.11	0.08	0.05	0.03	0.02	0.01

CAUTION

- 1. Net rated loads are performance when the crane is placed level and is based on an actual working radius including boom deflection under load.
 - Rated loads are also based on the strength of the crane and the stability of the crawler.
- 2. Rated loads must be reduced in accordance with wind, ground condition and operating speed.
- 3. The mass of hook, slings, and any accessories to the boom or load line must be deducted from the rated load in the chart.
- 4. When the outriggers are set without extending to their maximum, stability of the crane deteriorates remarkably.
 - Pay attention that the rated loads are changed according to how far the outriggers are extended.
- 5. If any one of the four outriggers is not fully extended, operate with performance of not maximum extension.
- 6. In order to make correct operation, read the instruction manual carefully before crane operation.

FLY JIB:(OPTION)

LIFTING CAPACITY:

710kg

JIB LENGTH:

2.0m

TILT ANGLE:

0°,20°,40°,60°

MASS OF FLY JIB:


95kg


NET RATED LOADS: (FOR FLY JIB)

						TILT A	NGLE							
	1st TC	4th BO	OM SEC	TIONS	ONL)	Y 5th BO	OM SEC	TION	ONL)	ONLY 6th BOOM SECTION				
BOOM ANGLE	0°	20°	40°	60°	0°	20°	40°	60°	0°	20°	40°	60°		
80°	700	700	700	700	450	450	450	450	150	150	150	150		
75°	700	700	700	700	450	450	400	400	150	150	150	150		
70°	500	500	400	400	300	300	200	200	100	100	100	100		
65°	350	350	200	200	150	150								
60°	200	200	100	100										
55°	100	100					·							
50°					DDOH	IBITED	1	IBITED	PROHIBITED AREA OF CRANE OPERATIONS					
40°	PROH	IBITED		IBITED		EA	1	EA RANE						
30°		EA	AR OF C	EA RANE		RANE		ATIONS	0. \	J. 0 12 C), <u> </u>	0,40		
20°		RANE	OPERA		OPERA	ATIONS								
10°	UPERA	ATIONS												
0°														

CAUTION


- 1. Net rated loads are performance when outriggers extended to maximum.
- 2. Net rated loads are performance when the crane is placed level and is based on an actual working radius including boom deflection under loaded.
 - Net rated loads are also based on strength and stability of the crane.
- 3. Net rated loads must be reduced in accordance with wind, ground condition and operating speed.
- 5. The mass of the slings and any accessories attached to the boom or load line must be deducted from the above net rated loads in the chart.
- 6. In order to make correct operation, read the instruction manual carefully before crane operation.






WORKING RANGE:

(FOR FLY JIB)





Note: The above figures are based on no-load condition and do not include the deflection of the boom.

FLY JIB-SEARCHER HOOK:(OPTION)

LIFTING CAPACITY:

700kg

SEARCHER HOOK LENGTH:

2.0m

TILT ANGLE:

0°,20°,40°,60°

MASS OF SEARCHER HOOK


8kg (Bracket and jib are excepted)


NET RATED LOADS: (FOR FLY JIB-SEARCHER HOOK)

1st 7	TO 4th BOO	OM SECTION	ONS	ON	ILY 5th BO	OM SECTI	ON	ONLY 6th BOOM SECTION				
	NET R	RATED LOA	AD(kg)		NET F	RATED LOA	AD(kg)	NET RATED L			AD(kg)	
WIRKING RADIUS (m)	OUTRIG. EXT. TO MAX.	OUTRIG. EXT. TO HALF.	OUTRIG. EXT. TO MIN.	WIRKING RADIUS (m)	OUTRIG. EXT. TO MAX.	OUTRIG. EXT. TO HALF.	OUTRIG. EXT. TO HALF.	WIRKING RADIUS (m)	OUTRIG. EXT. TO MAX.	OUTRIG. EXT. TO HALF.	OUTRIG. EXT. TO MIN.	
4.5	700	700	700	4.0	450	450	450	5.0	150	150	150	
5.0	500	500	450	5.0	400	400	400	5.5	150	150	150	
6.0	400	400	300	6.0	300	300	200	6.0	130	130	130	
7.0	350	300	100	7.0	250	250	100	7.0	100	100	100	
8.0	300	200		8.0	200	200		8.0				
9.0	250	100	PROHIBITED	9.0	150	150		9.0				
10.0	150	PROHIBITED	AREA OF CRANE	10.0	130	100	PROHIBITED	10.0				
11.0	100	AREA OF CRANE	OPERATION	11.0	100		AREA OF CRANE	11.0	DDOLL	יטודכט אט	_,	
12.1	PROHIBITED AREA	OPERATION		12.0	PROHIBITED	PROHIBITED AREA OF	OPERATION	12.0		IBITED AR NE OPERA		
				13.0	AREA OF CRANE	CRANE OPERATION		13.0	0.0.0	12 01 2101		
				14.2	OPERATION			14.0				
								15.0)			
								16.4				

CAUTION

- 1. Net rated loads are performance when the crane is placed level and is based on an actual working radius including boom deflection under loaded.
 - Net rated loads are also based on strength and stability of the crane.
- 2. Net rated loads must be reduced in accordance with wind, ground condition and operating speed.
- 3. The mass of the slings and any accessories attached to the boom or load line must be deducted from the above net rated loads in the chart.
- 4. In order to make correct operation, read the instruction manual carefully before crane operation.
- 5. Do not use the main hook when using the searcher hook.





7161

SEARCHER HOOK: (OPTION)

LIFTING CAPACITY:

500kg

SEARCHER HOOK LENGTH:

0.8m

TILT ANGLE:

0°,20°,40°,60°

MASS OF SEARCHER HOOK:


20kg


NET RATED LOADS: (FOR SEARCHER HOOK)


1s	t TO 5th BOO	OM SECTIO	NS	(ONLY 6th BO	OOM SECTION	1	
	NET	RATED LO	AD (kg)		NET	RATED LOA	AD (kg)	
WORKING RADIUS (m)	OUTRIG. EXT. TO MAX.	OUTRIG. EXT. TO HALF.	OUTRIG. EXT. TO MIN.	WORKING RADIUS (m)	OUTRIG. EXT. TO MAX.	OUTRIG. EXT. TO HALF.	OUTRIG. EXT. TO MIN.	
2.0	500	500	500	2.0	280	280	280	
3.0	500	500	500	3.0	280	280	280	
4.0	500	500	500	4.0	280	280	280	
5.0	500	500	500	5.0	250	250	250	
6.0	420	420	350	6.0	220	220	220	
7.0	340	340	200	7.0	190	190	170	
8.0	290	270	130	8.0	170	150	120	
9.0	250	200	80	9.0	150	120	80	
10.0	220	150	50	10.0	130	100	50	
11.0	200	110		11.0	110	70		
12.0	180	80	PROHIBITED AREA OF CRANE OPERATION	12.0	100	50		
13.06	160	60		13.0	80		PROHIBITED AREA OF CRANE OPERATION	
				14.0	70	PROHIBITED AREA OF CRANE OPERATION	5.2.05	
				15.25	50			


CAUTION

- 1. Net rated loads are performance when the crane is placed level and is based on an actual working radius including boom deflection under loaded.
 - Net rated loads are also based on strength and stability of the crane.
- 2. Net rated loads must be reduced in accordance with wind, ground condition and operating speed.
- 3. The mass of the slings and any accessories attached to the boom or load line must be deducted from the above net rated loads in the chart.
- 4. In order to make correct operation, read the instruction manual carefully before crane operation.
- 5. Do not use the main hook when using the searcher hook.









CC-1161